

All RIGH

Tél. : +33 (0)2 43 60 78 60 - Fax : +33 (0)2 43 93 41 94 e-mail : clients@de72.fr

### Technical file NF001 G

# **Open only**

## CEO1 - CEO1-10 - CEO2 - CEO2-10

#### **REMINDER** :

Height of installation: §9.1 of the NFS 61-932

The safety device to be used should be fitted at a height of between 0.90m and 1.30m from the ground.

Pipes and connections: §7.2 of the NFS61-932

Pipes should be made entirely of copper or stainless steel. Connections should be airtight, metal against metal.

Pneumatic piping should run through the interior of the building, to avoid the risk of freezing.

Performance and testing: §6.4 of the NFS61-932

The calculation to define the capacity required should be based on the characteristics of the components of the system to be fed and should take into account the characteristics of the circuit.

The pressure should be checked using a specialised tool (for example a pressure gauge) in order to make sure that the pressure present in the circuit corresponds to this calculation. In addition, this tool will check the airtightness of the circuit.

#### Installation

Lift off the front cover.

Check that the wall or hanging surface is completely flat, in order to ensure that the box is fitted correctly.

Fix the back of the box to the wall or hanging surface.

Connect the box to the copper circuit.

Put the pipe into the joint, tighten manually and then with a spanner, until it is secure. (1.5 turns maximum)

#### Testing

Check that the pin is in the down position. (If not, see the resetting step)

Screw the CO<sup>2</sup> cartridge in place MANUALLY.

Carry out the manual triggering action by pulling the ring.

Drain the CO<sup>2</sup> from the circuit by unscrewing the cartridge.

Proceed to the resetting of the box. (See below)

#### Resetting

Unscrew the pierced cartridge. Push back the plate spring (1) and lift up the lever (2).



Push down the pin until it is blocked back into place using a non-metallic tool (eg. the handle of a screwdriver) to avoid damanging the tip.



The pin holder should protrude from the bottom of the pin hammer block.



#### Installation (continued)

Screw the cartridge onto the pin hammer. Put the spare cartridge in place. Use the pre cut-out on the cover to pass through the pipe. Put the flap in place on the cover. Replace the front cover.

#### SMOKE EXHAUST Use

In the case of a fire, pull open the flap and pull the ring.

#### Maintenance

<u>THE PRODUCT</u>, every 6 months. Check that everything is in good working order. Check the condition of the pins. <u>INSTALLATION</u>, see according to norm NFS61-933

#### Easy installation, useful material

To carry out the installation of this product, you will need the following :	
Pressure control kit	KIP01
Safety cabinet	BP300
Copper piping	TCB506
Copper reel	TCC2506
Clamp Ø6 by 100uts	COL6M100
Straight joint	RAU2621
Tjoint	RAU2623
Elbowjoint	RAU2622
Steel piping	TAT2508
Metaltrunking	GM201
Plastic trunking	GP2210
CO <sup>2</sup> Cartridge	CARDE50

#### **Technical Characteristics**

Material	. :Steel, brass, aluminium.
Protection	. :Zinc coating: RAL3000 / 1013
	. :To be handled with the fingers, paint RAL3000.
Force to be applied	
Protection index	.:IP42.
Energy	. :Co² or inert gas.
DCM exit	: Olive screw connection
Temperature during use	:+ 5°C to + 50°C
Pressure	. :operating = 3 to 20 bar
	. in use = 60 bar
	. during testing = 90 bar.

 $CO^2$  cartridge pitch 15 x 125

Precautions.....:Stock and install away from bad weather conditions.

Les Ajeux - 72400 La Ferté Bernard - France www.dupuy-equipements.com



