Bottom hung INWARD OPENING MECHANICAL EXUFACE

OPEN ONLY OPERATED BY OIL PNEUMATIC SPRINGS

CFIN1MTxxVxRx

Description


The Mechanical EXUFACE O/O, a CE certified facade SHEV window, has been designed to be incorporated easily and stylishly into all types of facade.

Its different versions, either mechanical or pneumatic, fully meet current regulatory requirements. Easy to connect, the Mechanical EXUFACE O/O is delivered with all its operating components already fitted in our factory.

Inconspicuously mounted, different types of locking pin mean it can be adapted to the nature of the control line. Its technical design means that on models over 1200mm wide, a second locking point ensures a tight fit of the sash against the frame base, providing perfect weathertightness.

Stylish, the EXUFACE can be delivered with the option of cladding painted to coordinate with the frame, thus hiding any unsightly components.

Excellent performance, the Mechanical EXUFACE O/O guarantees 10,000 cycles of ventilation and 1,000 cycles of smoke exhaust !





Technical File CE/NF018a

0

Bottom hung INWARD OPENING MECHANICAL EXUFACE

Standard cross-sections

Installation in an insulated wall

OPEN ONLY OPERATED BY OIL PNEUMATIC SPRINGS

CFIN1MTxxVxRx

Technical Characteristics

Material: Aluminium, glass, steel, synthetic material. Protection: Varnishing, zinc coating. Precautions: Stock and install away from bad weather conditions.

Opening direction Minimum Range of dimensions Maximum Bottom hung Inward opening

Declared Characteristics


Aerodynamic Free Area "Aa" (consult us)	: Depending on dimensions
Wind Load "WL"	: 1500
Snow Load "SL"	: Does not apply
Low ambient Temperature "T"	: 00
Reliability "Re"	: 1 000 + 10 000 cycles ventilation
Heat Resistance "B _{wall} "	: 300
Reaction to fire	: A1
Temperature of thermal triggering	: Does not apply
Type of SHEV mechanism : Type A (open only)	

Options

- Position contacts open / close

- Finishings such as flashings, trim, joint covers ...

How to measure the window



Substract a minimum of 5mm from the dimensions of the height and width of the cavity in the wall.

Eg. : for a cavity of 900h x 1400, the total dimensions of the window will be 890h x 1390

Installation

When installing the window,

First fix the window in place, 2 support wedges per side.
Make sure the frame base is squared up by checking 2

opposite angles - Check the plumb of the frame base, any vertical misalignment should be less than 2mm per metre. The installation, fixings and weathertightness should be carried out in accordance with the norm NF DTU 36.5 in force.

Product identification

Product delivered with markings translated

